

MODEL: 50325DT

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS FOUNTAIN SHOULD TAKE APPROXIMATELY 20 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.


CAUTION:
TWO PEOPLE REQUIRED TO LIFT AND ASSEMBLE THIS FOUNTAIN.

UNPACK THE FOUNTAIN


YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS: UPPER COLUMN, UPPER RESERVOIR, LOWER COLUMN, LOWER RESERVOIR, BASE, PUMP, (2) SPOT LIGHTS, (2) EXTRA BULBS AND TRANSFORMER.

FOUNTAIN ASSEMBLY


1. PLACE LOWER RESERVOIR ON TOP OF BASE AND ROTATE THE LOWER RESERVOIR CLOCKWISE TO SECURE.



2. FEED THE PUMP POWER CORD AND LIGHT POWER CORD THROUGH THE PLASTIC TUBE TOWARD BOTTOM OF BASE, CORD EXITS OUT FROM CHANNEL ON THE BOTTOM OF THE BASE.




3. PLACE PUMP FLAT IN LOWER RESERVOIR AND PLACE (2) SPOT LIGHTS INTO SPOT LIGHT HOLDERS.




MODEL: 50325DT
ASSEMBLY INSTRUCTIONS
READ AND SAVE THESE INSTRUCTIONS

FOUNTAIN ASSEMBLY


4. PLACE UPPER RESERVOIR ONTO TOP OF LOWER COLUMN AND ROTATE THE UPPER RESERVOIR CLOCKWISE TO SECURE.



5. PLACE UPPER COLUMN INTO UPPER RESERVOIR.



6. LIFT THE UPPER RESERVOIR ASSEMBLY, ATTACH RUBBER HOSE TO PUMP, THEN PLACE UPPER RESERVOIR ASSEMBLY INTO LOWER RESERVOIR, MAKE SURE PUMP SIT FLAT IN LOWER RESERVOIR.



MODEL: 50325DT

ASSEMBLY INSTRUCTIONS


READ AND SAVE THESE INSTRUCTIONS

FOUNTAIN ASSEMBLY

7. FILL RESERVOIR WITH 5 GALLONS OF WATER TO COMPLETELY SUBMERSE THE PUMP.

NOTE: DISTILLED WATER IS RECOMMENDED TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD-UP.)

8. JOIN THE CONNECTORS AT TRANSFORMER AND SCREW THE CAP TO CONNECTOR TIGHTLY TOGETHER.



9. PLUG PUMP POWER CORD AND TRANSFORMER INTO SOCKETS, YOUR NEW FOUNTAIN IS READY FOR USE.

TROUBLE SHOOTING:

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.

2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.

3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

SPLASHING DISCLAIMER:

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

IMPORTANT PUMP INFORMATION:

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

WATER:

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

WARNING:

* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD-UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

** THIS FOUNTAIN IS RATED FOR OUTDOOR USE.

*** THIS UNIT MUST BE CONNECTED TO A SUPPLY CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). THE GFCI SHOULD BE TESTED ON A ROUTINE BASIS. TO TEST THE GFCI, PUSH THE TEST BUTTON. THE GFCI SHOULD INTERRUPT POWER. PUSH THE RESET BUTTON. POWER SHOULD BE RESTORED. IF THE GFCI FAILS TO OPERATE IN THIS MANNER, THE GFCI IS DEFECTIVE.

AVAILABLE PARTS ARE:

PUMP1008 (PUMP)
TRANS2002 (TRANSFORMER)
53205BLB (BULB)